



ADVANTEK

# Assembly Instruction

## THE PRARIE HOME (LARGE)

CHICKEN COOP

ITEM: #21944AC

A SCREWS 3.5\*40 17PCS

C BOLTS M6\*55 8PCS

E 1 PC

B SCREWS 3.0\*25 19PCS

D SCREWS 3.5\*50 8PCS

